



## Resistance 3D Panelling™ Installation Guide

**Installation Tools** – Circular Saw, Tape Measure, nail free Glue and a C-Brad nail gun. If you don't have access to a nail gun you will need a small bullet head panel pin to be hand nailed through the edge of the panel.

### Installation guide for fixing to Gyprock or timber studs/battens-

1. Pre-work for plasterboard or plywood is recommended before installation to remove any materials that may affect the glue sticking to the surface. You must remove existing wallpaper before installation.
2. Measure the areas to be covered with your new wall panelling to ensure you have enough material and the correct lengths to complete your work.
3. Apply your nail Free glue (we recommend Soudal – strong as nails) to the back of your starter trim and fix to wall with your fixing gun (C1 or C brad recommended) making sure it is close to the edge of the board to ensure it is covered by the next panel to be installed.
4. Continue to install the remaining panels with the same procedure using nail free glue and fixing each panel with a small brad nail on the edge of each board that will be covered by the overhang on the next board.
5. Cut the final board to fit to the correct distance from the end of the wall allowing for the end trim to be fitted if required.
6. For external wrap around corners, combine the two grooves to fit together and work your way back from the corner in each direction.
7. The end trim can be used to finish the top or bottom of the panels if your panelling is not going to the full height of your wall.

### Installation guide for fixing to brick or rendered walls –

1. Use all the same steps as above for the installation and by using Soudal' s T-Rex Fast Grab you will not require nails as part of the fixing process.
2. It is recommended to install smaller areas of around one metre in the width of the wall and allowing the glue to cure for around ½ hour before commencing. Repeat this pattern until completed.
3. Throughout the process ensure you remove any glue that may have been split on the face of the panelling immediately with an approved cleaner. Soudal' s Swipex cleaning wipes are recommended when using any of the Soudal adhesives.